



- E22 - Windshield Wiper/Washer Switch
- E38 - Windshield Wiper Intermittent Regulator
- J31 - Wiper/Washer Intermittent Relay
- V5 - Windshield Washer Pump

- (249) - Ground connection -2-, in wiring harness interior
- (277) - Ground connector -3-, in wiring harness interior
- (A96) - Connector (53a), in instrument panel wiring harness
- (A97) - Connector (53), in instrument panel wiring harness

ws = white  
 sw = black  
 ro = red  
 br = brown  
 gn = green  
 bl = blue  
 gr = grey  
 li = violet  
 ge = yellow  
 or = orange

**HOT SIDE SWITCHING**  
 WIPERS RUN WHEN 12V APPLIED TO  
 WIPER MOTOR SLOW OR FAST TERMINALS.  
 MOTOR COMMON AT GROUND.