



- | | |
|-----|---|
| 2 | Ignition switch |
| 11 | Fusebox |
| 29 | Positive terminal |
| 31 | Ground panel in central electrical unit |
| 47 | Switch |
| 117 | Interval relay |
| 163 | Windshield wiper motor |
| 164 | Washer motor |
| 207 | Horn |
-
- | | |
|---|-----------------------------------|
| A | Ground point, right A-post |
| B | Ground connection at front fender |
| C | Connector, left A-post |
| H | Windshield wiper connector |
-
- | | |
|----------|------|
| Fuse No. | Horn |
| 15 | |

Washer & Wiper Wiring Circuit (Front)

HOT SIDE SWITCHING

WIPERS RUN WHEN 12V APPLIED TO WIPER MOTOR SLOW OR FAST TERMINALS. MOTOR COMMON AT GROUND.

RainTracker™
VEHICLE INTERFACE
WIRING DIAGRAM

© 2004 OPTO-ELECTRONIC DESIGN, INC